



Quick Technique for Appliqué using True Type Fonts

By: Brother Education Department

1. Open PE Design 7.0, layout and editing.
2. On the left tool bar, select the letter A. On the fly-out menu, select the first letter.
3. From the top tool bar pull down menu select the TT font you want to use. This will only work with the TT fonts. A bold font works best for this technique.
4. Type in the word you wish to use.
5. Use the selector tool to select the word and make it the size you want it to be when finished. Large letters work extremely well.
6. Turn off the fill stitches to the design.
7. Make sure the outline stitch style is set to "running stitch"
8. Using the icons on the tool bar, select the thread spool and change the color to: "appliqué position". Appliqué position is at the very bottom of the thread color chart.



9. Using the icons on the tool bar select copy, then paste. Then select the thread spool again and change the thread spool color of the pasted design to appliqué material.
10. From the icons on the tool bar, again select copy, then paste. Now change the thread spool color of the pasted design to "appliqué". Also change the stitch selection on the outline stitch from running to zigzag stitch.
11. Select 123 sewing order on the tool bar and you will see your 3 step appliqué letters.



12. Save your design and enjoy the easy appliqué process!